



# White Knight

## Instant Clear Finish Fact Sheet

---

White Knight Instant Clear Finish is a polyurethane-based, hard-wearing finish. The protective finish has excellent resistance to abrasion, hot water, alcohol and most household chemicals.

### Suitable Surfaces

Instant Clear Finish is suitable for all interior wood including furniture, doors, architraves, timber panelling, floors and veneer. Note: Instant Clear Satin is not suitable for use on floors.

### Preparation

The surface to be coated must be thoroughly sanded to a smooth finish. Fill nail holes and cracks with appropriate timber putty and sand smooth. Sand in the direction of the grain with #220 grade paper. The surface must be cleaned, dry and free from grease, oil, dirt, sanding dust and other contaminants. **NEW TIMBER TO BE CLEAR COATED:** Prepare surface as outlined above. **NEW TIMBER " NEW TIMBER TO BE STAINED AND CLEAR COATED:** Prepare timber as detailed above then apply stain as per label directions and allow to dry before coating. **PREVIOUSLY CLEAR FINISHED TIMBER** Prepare surface as outlined above. Sanding the existing finish is essential to achieve adhesion of topcoats. Before painting do a representative test area to ensure compatibility with the old coating. **BEFORE SPRAYING** Cover all necessary areas to protect from overspray. It is essential to shake the can for at least one minute after mixing ball rattles to ensure product uniformity. Shake can occasionally during use.

### Application Details

**Brush:** Stir thoroughly with a broad, flat stirrer before and during use. Do not shake to avoid air entrapment. Apply using a brush. To prevent runs avoid overloading the brush. Final brush strokes should be made with the grain to ensure even appearance. Do not use when the air or surface temperature is below 10°C or above 30°C. **Aerosol:** Do not use when the air or surface temperature is below 15°C or above 30°C or in excessive humidity. Spray outside or in a well ventilated area away from fire and heaters. Test spray first on a small inconspicuous area to ensure surface compatibility and finish suitability. Hold the can upright approximately 15-20 cm from the surface. Press button firmly. Spray with a smooth sweeping motion. Apply a pre-wetting mist coat followed by a full even coat. Overlap each spray pass. Repeat if necessary. To prevent paint sagging, avoid spraying too close to the surface or spraying too heavy a coat. **NEW AND STAINED TIMBER** Apply two or more coats of Instant Clear Finish, lightly sanding with #400 grade paper between coats. **PREVIOUSLY CLEAR FINISHED TIMBER** Apply one to two coats of Instant Clear Finish, lightly sanding with #400 grade paper between coats.

### Coverage

**Brush on:** Up to 14 square metres per litre depending on the nature of the surface. **Aerosol:** Up to 1 - 1.5 square metres per unit depending on the nature of the surface and the amount of overspray.

### Drying Times

**Touch dry** **Brush on:** 2 hours. **Aerosol:** 1 hour. Drying times will be slower in cold or humid conditions, in the absence of ventilation or where heavy film builds are applied **Re-Coat:** **Brush on:** After 8 hours. **Aerosol:** After 8 hours

### Clean Up

Wash brushes and equipment with mineral turps immediately after use.

### Pack Sizes

300g spray, 500ml, 1 litre, 2 litre, 4 litre Available in Gloss (suitable for floors), Satin and Matt

### Health and Safety

Refer to Material Safety Data Sheet available by request on 131 686.

---

## Got more questions? Need help? Want a brochure? Any comments or suggestions on the site?

If you have any comments or questions on the White Knight range or want more information we are here to help.

### Contact Us

#### Customer Care Advisers

Phone 131 686

Fax 1800 676 756

Opening Hours: Mon-Fri 8am to 7pm EST, Sat/Sun 9am to 4pm EST

Email [info@whiteknightpaints.com.au](mailto:info@whiteknightpaints.com.au)